



<p>BT1 Botonera Bot-07 Philco – Daewo</p> 	<p>BT2 Botonera Bot-09 Philco – Daewo – Serie Dorada</p> 	<p>BT3 Botonera Bot-10 Philco – Daewo</p> 	<p>BT4 Botonera Bot-06 Philco – Daewo – LG-Con refuerzo</p> 	<p>BT5 Botonera Bot-11 Philco – Daewo Original</p> 
<p>BT6 Botonera Bot-16 8 botones</p> 	<p>BT7 Botonera lágrima Philips – Power Vision</p> 	<p>BT8 Botonera Bot-01 Sharp – Samsung – Mitsubishi</p> 	<p>BT9 Botonera Bot-02 Sanyo</p> 	<p>BT10 Botonera Bot-03 Samsung – Hanover</p> 
<p>BT11 Botonera Bot-08 Philco – Noblex</p> 	<p>BT12 Botonera Bot-05 Philco – Firstline</p> 	<p>BT13 Botonera Bot-19 Broksonic</p> 	<p>BT14 Botonera Bot-12 Philco</p> 	<p>BT15 Botonera Bot-14 Philco invertida</p> 
<p>BT16 Botonera Bot-13 Philco – Broksonic doble</p> 	<p>BT17 Botonera Bot-15 Sampo</p> 	<p>BT18 Botonera Bot-17 Broksonic-Goldstar- Samsung</p> 	<p>BT19 Botonera Bot-18 Broksonic</p> 	<p>BT21 Botonera estéreo Philips DC 401</p> 
<p>BT22 Botonera Gris 6 botones</p> 	<p>BT23 Botonera Bot-04 Sharp – Samsung – Mitsubishi</p> 			